

By WIFI Program Message Manual

Package include: 1 x Led sign with signal receiver, 1 x Ac plug, 1 x CD with Manual


You can program your message in anytime, anywhere by WIFI.

- Please power on the led sign, keep the wifi signal receiver upright.
- Install the software on your notebook, and following below steps to set the led sign technical parameters and program message if by WIFI to update message:



1. Open the CD and install the software “PowerLed V2.80.3”.




2. Open the software, choose the program window language: Options -Language- English or change to other language.




3. Click Net shared center, you'll find the TF_9B6A32 , connect it, it's not open network, it can work if you see a yellow mark on it, just make sure connected TF_9B6A32 before you do next steps.





4. Make sure connected well the WIFI, then click Tools Search




5. Search the Led sign controller, Click OK.




6. Click “Program”, add “Text”, “Time” and etc.




7. Program the content and set message effect here: You can choose letter font, spd(speed), Act(Display effect) etc.



8. Program your message, set the action, speed what you like, click “PV” to preview the effect. Usually spd:14 is ok or smaller number will be faster Speed.



9. After finish program, tick the message you want the led display to show, then click send, after 1 sec., the screen will show your message.



No need internet, just connect your PC with led sign wifi hot point.